



Multi-Tilt Control Adjustments

To get the maximum benefits from your Ergonomic Chair,
please use the individual adjustments.
Sit as far back in the seat as comfortable and lean against the
backrest.

Right Side When Seated

Left Side When Seated

(A) Back Angle—To adjust, lift the lever up and move the back to the desired position. Push the lever down to lock in position.

(B) Pneumatic Seat Height—To lower the seat height, lift up on the lever while seated. Release the lever when at the desired height. To raise the seat, lift your weight off the seat while pulling up on the lever.

(C) Infinite Tilt Lock—Locks the chair in any position and free floats when unlocked. To lock the chair in a given position, push the lever down. To release the lock and have the chair free float—lift the lever.

(E) Seat Depth—While seated in the chair—lift up the lever and slide the seat to the desired depth based on your body size.

(F) Tension Control—Turn the knob on the front of the mechanism, clockwise to tighten and counter clockwise to loosen the tension.

(D) Forward Tilt—Adjust the forward tilt from 0 to 5 degrees. Lean back while the seat is in free float mode and turn the lever clockwise to increase the seat angle and counterclockwise to reduce the seat angle to the desired position.

